Intec's Cyclone

Follow these steps to return tool to rentable condition:

Step	Action
Safety First	**Make sure you put on all appropriate safety equipment before you begin turning this tool. For additional reference, refer to the Equipment Operation and Safety guide or Vendor Instruction Manual.**
1	Inspect hose for damage including cuts, kinks, and flat areas. Replace hose if current exhibits these or other defects.
2	Inspect wired remote to ensure no cuts or frays in the wire. If damaged, repair prior to returning to rentable condition.
3	Inspect Airlock Seals - Every 100 hours inspect airlock seals – This is a key aspect in assuring your Intec machine is performing at maximum level. Inspect seals for wear, cuts, or curling. Also, if you notice material blowing back into the hopper, then you have a bad airlock seal. The most accurate way to test the quality of the seals is to perform a psi test. If the readings are level, then your seals are operational. If the reading is not level and "jumps" then you have a bad seal.
4	Inspect Paddles - Inspect agitator paddles for wear and cracking. Replace when signs of aging appear to maintain optimum performance.
5	Inspect Power Cord – Inspect power cord after every use for cuts or tears. Repair or replace if defects occur.
6	Lubricate Chain - Every 6 months, lubricate the drive chain using a dry lube only.
7	Check Chain Tension & Alignment - Every 6 months to assure proper tension and alignment while machine is off. Also check visually when running (make sure to wear the proper safety equipment when performing maintenance and checks.
8	Blower – Use compressed air to blow out motor and intake of blower every 20-30 hours of use to maximize blower impeller and motor life. Inspect blower brushes every three months or 100 hours of use. Replace brushes when they reach 1⁄4 inch or less in length. Change the brushes before the brush stunt touches the commutator. When reassembling, the lead wires must be isolated from the motor frame and any rotating parts.
9	The tool is now ready to be returned to the shelf for rental.

Note:	Turning this tool and attaching a new service tag with **your signature** is extremely important. This is your assurance that the tool is not defective and is in good working condition when the customer rents it.

Labels	Ensure all required Safety and Rental labels are intact and appropriately affixed to the tool.